





MESH Wireless

Design Francisco Gomez Paz, 2018

LUCE
PLAN

Type:	Suspension		
Light source:	D86KW080	LED 50W 2700K	EEL : A
	D86KW100	LED 61W 2700K	EEL : A
Minimum App requirement:	 		
Network requirement:	 WiFi 2,4 GHz		
Product use:	Indoor		
Materials:	Structure in steel, lenses in polycarbonate		
Colors:	Black		
Description:	Thanks to a wireless kit available for the Mesh suspensions large (Ø 100) and medium (Ø 80), users can interact with the lamp by means of a smart device. Luceplan has developed a special app (for iOS and Android) that makes it possible to control single or multiple units, individually or as a group.		

Insulation class: 

Reference code: Structure

Mesh complete, kit wireless included, Ø 80 cm


D86KW081	1D86KW081001A	cable lenght 1 m
D86KW082	1D86KW082001A	cable lenght 2 m
D86KW083	1D86KW083001A	cable lenght 3 m
D86KW084	1D86KW084001A	cable lenght 4 m
D86KW085	1D86KW085001A	cable lenght 5 m

Mesh complete, kit wireless included, Ø 100 cm

D86KW101	1D86KW101001A	cable lenght 1 m
D86KW102	1D86KW102001A	cable lenght 2 m
D86KW103	1D86KW103001A	cable lenght 3 m
D86KW104	1D86KW104001A	cable lenght 4 m
D86KW105	1D86KW105001A	cable lenght 5 m




D86KW80







Ceiling rose: Ø 30 x 7 cm

D86KW100




Ceiling rose: Ø 30 x 7 cm






Luceplan Mesh




Google Play
App Store

Don't use characters: . , " ° £ /

APP:  www.luceplan.com/products/mesh-wireless

Mesh master PSK  luceplan

Light scenarios




MESH Wireless

Design Francisco Gomez Paz

LUCE
PLAN

HOW TO INSTALL Mesh wireless controlled by wall buttons.
(This does not require uninstalling the Mesh App)




MESH Wireless

Design Francisco Gomez Paz

LUCE
PLAN

HOW IT WORKS

Mesh is controlled by a dedicated electronic board which is located in the ceiling rose. The board needs to be connected to a normally open push button in order to dim the light or to control the different scenes, and to an on/off switch.




HOW IT WORKS (choose the scenario)

PRESET SCENARIO


1. COMPLETE

2. LOWER ZONE




x2


Press the button
twice to select
scenarios



x2




x2



x2

4. YOUR SCENARIO

5. YOUR SCENARIO



x2

